



Safer • Simpler • Smarter

KEYPAD ENTRY SYSTEM CODING



YOUR EXISTING CODE IS:

8552

SHORT-FORM KEYPAD CODE CHANGE INSTRUCTIONS

To ReProgram Keypad including removing old code

<i>Follow all steps below exactly on the keypad on a powered on compactor:</i>	Enter exactly what you see in the left column
725	This is the programming code
111111	Overall system code
1	Pause for 1 or 2 seconds max
11	Index to remove old codes
1	Pause for 1 or 2 seconds max
4	Number of digits in new code (or 5 if you prefer)
XXXX	This is your new code but no 1's or 9's
0	Ends reprogramming

To Add A Code

<i>Follow all steps below exactly on the keypad on a powered on compactor:</i>	Enter exactly what you see in the left column
#111111	Overall system code – include the #sign
1	Pause for 1 or 2 seconds max
12	Door timing-relatch code
1	Pause for 1 or 2 seconds max
4	Number of digits in new code (or 5 if you prefer)
XXXX	This is your new code but no 1's or 9's
0	Ends reprogramming